

# Typical ProLine Drain Installation Details

Note: Set all Quick Slope and Flat Panel on structurally sound, flat sub-floor with fast-setting, self-curing thinset.  
Set the drain body level. Do not follow sub-floor if it is out of level.  
WAVES is the only recommended strainer pattern for a drain installed at the entry to a curbless shower.  
5 g.p.m. is the maximum recommended water flow for a drain installed at the entry to a curbless shower.  
Do not grout in strainer. Strainer must remain removable for maintenance.

